


INSTRUCTIONS



Single color flash patterns

		FPM	MS	
1	Single Flash	150	400MS	单闪
2	Double Flash	150	400MS	双闪
3	Triple Flash	150	400MS	三闪
4	Quintuple Flash	75	800MS	五闪
5	Slow Single Flash	75	800MS	单闪慢
6	Two adjacent groups flash alternately	150	400MS	相邻两组交替闪
7	Left and Right Flash alternately	150	400MS	整灯左右交替闪三闪
8	Rotation	-	-	顺时针旋转
9	Left Steady Burn (40%), Right Triple Flash	150	400MS	整灯左常亮 40%亮度 右三闪
10	Right Steady Burn (40%), Left Triple Flash	150	400MS	整灯右常亮 40%亮度 左三闪

* FPM means how many cycles in a minute


Dual color flash patterns

		FPM	MS	
1	Single Flash	150 / 2	400MS * 2	单闪
2	Double Flash	150 / 2	400MS * 2	双闪
3	Triple Flash	150 / 2	400MS * 2	三闪
4	Quintuple Flash	75 / 2	800MS * 2	五闪
5	Slow Single Flash	75 / 2	800MS * 2	单闪慢
6	Two adjacent groups flash alternately	150 / 2	400MS * 2	相邻两组交替闪
7	Left and Right Flash alternately	150 / 2	400MS * 2	整灯左右交替闪三闪
8	Rotation	-	-	顺时针旋转
9	Left Steady Burn (40%), Right Triple Flash	150 / 2	400MS * 2	整灯左常亮 40%亮度 右三闪
10	Right Steady Burn (40%), Left Triple Flash	150 / 2	400MS * 2	整灯右常亮 40%亮度 左三闪

* FPM means how many cycles in a minute

INSTRUCTIONS

1. Turn on **Color 1 ON/OFF** ,
2. Trun on **ALL** , and the will be be flashing, press next pattern to change pattern.
3. If you need dual color, please turn on **Color 2 ON/OFF** too.



- 50%** Adjust brightness to 50%
- Auto Sensor** Automatically senses day or night, automatically adjusts the brightness to 100% during the day and 50% at night, ECE R65 Class 2 (by day, by night), SAE J845 Class 1
- Indicator** Turn off screen display
- Cruise Light** Keep the warning lights in steady burn mode
- Random** All flashing patterns mixed together and keep changing in every five cycles.
- Favorite Pattern** You can customize your most commonly used or favorite pattern.
- Left** Traffic advisor, directing vehicles to the left.
- Traffic Advisor** Traffic advisor, directing vehicles to both sides.
- Right** Traffic advisor, directing vehicles to the right